
Actuation systems


Actuation systems are the elements of control systems which are responsible for transforming the output of a microcontrollers or microprocessor or control system into a controlling action on machine or device



eg. Pneumatic, hydraulic, mechanical, and electrical actuation systems

Pneumatic & hydraulic actuation systems

- Pneumatic deals with air pressure
- Hydraulic deals with fluid motion and pressure




Typical Hydraulic Power System

With a hydraulic system, pressurized oil (fluid) is provided by a pump driven by an electrical motor.


•The pump pumps oil from a sump through a non return valve and an accumulator to the system, from which it return to the sump.

- The pressure relief valve is to release the pressure if it rises above a safe level.
- The accumulator is ¹ to smooth out any short term fluctuations in the output oil pressure




Typical Hydraulic Power System

- The Accumulator Work
- Accumulator is a container in which the oil is held under pressure against an external force, which involves gas within a bladder in the chamber containing the hydraulic fluid
- If the oil pressure rises then the bladder contracts increase the volume the oil can occupy and so reduces the pressure.
- If the oil pressure falls the bladder expands to reduce the volume occupied by the oil and so increases its pressure.



Typical Pneumatic Power System




Directional Control Valves-1

- Pneumatic and hydraulic systems use directional control valves to direct the flow of fluid through a system; its ON/OFF devices either completely open or closed
- They might be activated to switch the fluid flow direction by means of mechanical, electrical or fluid pressure signal

Directional Control Valves-2 Common Types:

1-Spool valve: Move horizontally within the valve body to control flow


•2-Rotary spool valve: have the same idea, when rotates opens and closes ports



Directional Control Valves-3

- 3-Poppet valve:
- This value is normally in closed condition. In this value, balls, discs or cones are used in conjunction with value seats to control the flow.


•When the pushbutton is depressed, the ball is pushed out of its seat and flow occurs as a result of port 1 being connected to port 2. When the button is released, the spring forces the ball back up against its seat and so closes off the flow.



Directional Control Valves-4

Directional valves


Free flow can only occur in one direction through the valve, flow in the other direction is blocked by spring.





 The valve symbol consists of square for each of its switching positions. Thus for the shown poppet valve there are two positions, one with the button not pressed and one with it pressed. Thus two positions valve will have two squares, a three positions valve have three squares.

Figure 7.7 (a) Flow path, (b) flow shut-off, (c) initial connections

arrow headed lines are used to indicate the directions of flow in each position closed flow lines; blocked off








Symbols of Valve actuation

It indicates the various ways the valves can be actuated (see Fig)

Ports are labeled


- 1 (or P) for pressure supply
- 3 (or T) for hydraulic return port
- 3 or 5 (or R or S) for pneumatic exhaust ports

2 or 5 (B or A) for output ports




Solenoid operated spool valve The valve is actuated by a current passing through the solenoid

and return to its original position by spring




- Fig. shows the symbol for a 3/2 valve, the connection is shown for initial state i.e.
- 1(P) is connected to 2(A); 3(R) is closed.
- When the solenoid is activated, it gives the state indicated by the symbols used in the square to which it is attached, i.e we now have 1(P) closed and 2(A) connected to 3(R). When current through the solenoid ceases the spring pushes the valve back to its initial position.

•The spring movement gives the state indicated by the symbols used in the square to which it is attached.



A 3/2 valve


 a simple example of an application of valves in a Pneumatic lift system



Pilot-operated valves

In pilot operated system one valve is used to control a second valve. In the Fig the pilot valve is small size and can be operated manually or by a solenoid.

It is used to overcome when the force required to move the ball shuttle in a valve can often be too large for manual or solenoid operation




Pressure control valve-1

Three main types


1- Pressure limiting valve: used to limit the pressure in a circuit to below some value

2- Pressure regulation valve: used to control the operating pressure in a circuit and maintain it at constant value.



Pressure control valve-2

3-Pressure sequence valve: are used to sense the pressure of an external line and give a signal when it reaches some preset value.




Hydraulic/Pneumatic linear actuators, Cylinders

- Both hydraulic and pneumatic actuators have the same principles, differences being in size
- The cylinder consists of a cylindrical tube along which a piston/ram can slide
- They are of two types:
- Single acting and double acting


Cylinders: Single acting

• Single acting: the control pressure is applied to one side of the piston



Cylinders: Single acting

When a current passes through the solenoid, the valve switches position and pressure is applied to move the piston along the cylinder. When current ceases, the valve reverts to it is initial position and the air is vent from the cylinder.




Control of a single-acting cylinder with

(a) no current through solenoid, (b) a current through the solenoid


Cylinders: Double acting

 Are used when control pressure are applied to both side of the piston. A different in pressure between the two sides results in motion of the piston (No spring).



Cylinders: Double acting

Current through one solenoid causes the piston to move in one direction.



Control of a double-acting cylinder with solenoid, (a) not activated, b) activated

Cylinder: Example


- A hydraulic cylinder to be used to move a work piece in a manufacturing operation through a distance of 250 mm in 15 s. if a force of 50 KN is required to move the work piece, what is the required working pressure and hydraulic liquid flow rate if a cylinder with a piston diameter of 150 mm is available.
- Solution:
- $A = \pi r^2 = \pi (0.15/2)^2 = 0.0117 \text{ m}^2$
- The working pressure = F/A = 50x10³/0.017=2.8 MPa
- The speed of a hydraulic cylinder = flow rate of the liquid through the cylinder
- v=Q/A
- Flow rate= A.v=0.0117(0.250/15)=29.5x10⁻⁴ m³/s

Cylinder sequencing

Many pneumatic or hydraulic control systems may require a sequence of extension and retraction of cylinders to occur. e.g Suppose we have two cylinders: A and B If the start button pressed; { piston A extends;

If fully extended then piston B extends; If both A and B fully extended then Piston A retracts;


If A is fully retracted have piston B retract}



Process Control Valve


- used to control the fluid flow rate
- A common form of pneumatic actuator used with process control valve is the diaphragm actuator.
- The diaphragm is made of rubber which sandwiched in it is centre between two circular steel discs.
- The effect of changes in the input pressure is to move the central part of the diaphragm. The force F on the shaft is the force that acting on the diaphragm= P x A
- Where P: gauge pressure =Control pressure-atmospheric pressure
- A: diaphragm area

The restoring force is provided by spring, so kx=PA




Process Control Valve

- Valve bodies & Plugs
- Fig shows a cross section of valve for the control of rate of flow of a fluid.
- The plug restricts the fluid flow and so its position determines the flow rate




Process Control Valve

- Forms of Valve Body & Plug
- Single seated: closed more tightly but required more force
- **Double seated**: less force is required, less tightly




Process Control Valve


- Shape of the Plug: determines the relation between the stem movement and the effect on the flow rate
- 3 types are commonly used
- Fig shows the relation between the stem displacement & flow rate as % of maximum



Rotary actuators

 A linear cylinder can, with suitable mechanical linkage be used to produce rotary movement through angles less than 360⁰





Another alternative is shown in Fig. is called:
vane type semi rotary.
A pressure difference
between the two parts
causes the vane to rotate.