

# Continuous-Time Filters

Hakan Kuntman, 2009



# Continuous-Time Filters

A filter is a twoport that shapes the spectrum of the input signal in order to obtain an output signal with the desired frequency content.

passbands where the frequency components are transmitted to the output and stopbands where they are rejected. Traditionally, such circuits working in the continuous-time domain have been designed as resistively terminated lossless LC filters

# Continuous-Time Filters

With the growing pressure towards microminiaturisation, inductors were found to be too bulky so that designers started to replace passive RLC filters by active RC circuits where gain, obtained from operational amplifiers (op amps), together with resistors and capacitors in feedback networks, was used to achieve complex poles.

One disadvantage of op amp-based active RC filters is the limited frequency range over which these circuits can be used: the finite bandwidth of op amps usually constrains the applications to be below 100 kHz, with performance deviations becoming increasingly worrisome and difficult to control as operating frequencies increase.




## Continuous-Time Filters

### Other active devices suitable for active filter applications

- Operational Transconductor Amplifier: OTA
- Current Conveyor: CCI, CCII, CCIII, CCCII, DDCCII, DVCCII etc.
- Current-Feedback Operational Amplifier: CFOA
- Current-Differencing Buffered Amplifier: CDBA
- Four-Terminal Floating Nullor: FTFN

# Continuous-Time Filters

Operational Transconductor Amplifier: OTA,  
Dual Output Transconductance Amplifier: DOTA




$$G = \frac{I_O}{V_{I1} - V_{I2}}$$

input currents  $I_1 = 0, I_2 = 0$

$G = f(I_A)$ , controlled by biasing current  $I_A$

# Continuous-Time Filters

Dual Output Operational Transconductance Amplifier: DOTA




$$I_o^+ = g_{m1}(V^+ - V^-)$$

$g_{m1}$  and  $g_{m2}$  are controlled by a common biasing current IA

$$I_o^- = g_{m2}(V^- - V^+)$$

# Continuous-Time Filters

## Current-Mode LP Filter



$$H(s) = \frac{a_0}{s^2 + b_1s + b_0}$$


$$\frac{gm1}{C_1} = \frac{b_0}{b_1}, \quad \frac{gm2}{C_2} = b_1, \quad a_0 = b_0$$

$$b_1 = \frac{\omega_p}{Q_p} \quad b_0 = \omega_p^2$$

$$\omega_p = \frac{\sqrt{gm1 \cdot gm2}}{\sqrt{C1 \cdot C2}} \quad Q_p = \frac{\sqrt{gm1 \cdot C2}}{\sqrt{gm2 \cdot C1}}$$

# Continuous-Time Filters

## Current-Mode BP Filter



$$H(s) = \frac{a_1 s}{s^2 + b_1 s + b_0}$$

$$\frac{g_{m1}}{C_1} = \frac{b_0}{b_1}, \quad \frac{g_{m2}}{C_2} = b_1, \quad \frac{g_{m3}}{C_2} = a_1$$

$$b_1 = \frac{\omega_p}{Q_p} \quad b_0 = \omega_p^2$$

$$\omega_p = \frac{\sqrt{g_{m1} \cdot \sqrt{g_{m2}}}}{\sqrt{C_1 \cdot \sqrt{C_2}}} \quad Q_p = \frac{\sqrt{g_{m1} \cdot \sqrt{C_2}}}{\sqrt{g_{m2} \cdot \sqrt{C_1}}}$$



# Continuous-Time Filters

## Current-Mode HP Filter


$$H(s) = \frac{a_2 s^2}{s^2 + b_1 s + b_0}$$

$$\frac{g_{m1}}{C_1} = \frac{b_0}{b_1}, \quad \frac{g_{m3}}{g_{m4}} = a_2,$$

$$\frac{g_{m2}}{C_2} = \frac{b_2}{a_2}$$


$$b_1 = \frac{\omega_p}{Q_p} \quad b_0 = \omega_p^2$$

$$\omega_p = \frac{\sqrt{g_{m1} \cdot \sqrt{g_{m2}} \sqrt{g_{m3}}}}{\sqrt{C_1 \cdot \sqrt{C_2}} \sqrt{g_{m4}}} \quad Q_p = \frac{\sqrt{g_{m1}} \sqrt{g_{m4}} \cdot \sqrt{C_2}}{\sqrt{g_{m2}} \sqrt{g_{m3}} \sqrt{C_1}}$$



# Continuous-Time Filters

## CCII Based Filters



Multi-Input Single-Output Filter

# Continuous-Time Filters

Setting the currents  $i_5 = i_4 = 0$  and applying an input current of  $i_2$  to the circuit, a low-pass filter function is obtained which is described by

$$\frac{i_{out}}{i_2} = \frac{G_2 G_3}{s^2 C_1 C_2 + s(C_1 + C_2)G_2 + G_2 G_3}$$

Taking the currents  $i_2 = i_5 = 0$  and applying an input current of  $i_4$  to the circuit, a band-pass filter function is obtained. The BP transfer function is given by

$$\frac{i_{out}}{i_4} = \frac{s C_1 G_3}{s^2 C_1 C_2 + s G_2 (C_1 + C_2) + G_2 G_3} \quad (3)$$

# Continuous-Time Filters

$$i_2 = -i_5$$

and

$$i_4 = i_5 \frac{G_2(C_1 + C_2)}{G_3 C_1}$$

a high-pass filter is obtained. The HP transfer function is described by

$$\frac{i_{out}}{i_5} = \frac{s^2 C_1 C_2}{s^2 C_1 C_2 + s G_2 (C_1 + C_2) + G_2 G_3}$$

# Continuous-Time Filters

The pole angular frequency and the quality factor of the filter are given by

$$\omega_o = \sqrt{\frac{G_2 G_3}{C_1 C_2}}$$

$$Q = \frac{1}{(C_1 + C_2)} \sqrt{\frac{C_1 C_2 G_3}{G_2}}$$

Interchanging resistors and capacitors (RC transformation) the low-pass filter converts to high-pass filter without any component matching

# Continuous-Time Filters

## CCII Based Filters

Realization of Current-Mode Third Order Butterworth Filters Employing Equal Valued Passive Elements and Unity Gain Buffers




Fig. 1. Third order Butterworth filters with all equal valued capacitors and resistors.

# Continuous-Time Filters

The current transfer function of the circuit in Fig. 1(a) is given as

$$\frac{i_0}{i_{in}} = \frac{sCG^2}{(G + sC)(G^2 + sCG + s^2C^2)} \quad (1)$$

Taking  $G = 1$  mho and  $C = 1$  F,

$$\frac{i_0}{i_{in}} = \frac{s}{(1 + 2s + s^3)} \quad (2)$$

Impedance and frequency scaling can easily be performed on the filter circuit to shift the center frequency to the desired value.

# Continuous-Time Filters

Performing RC-CR transformation to the circuit which because of symmetry requires only the lower grounded capacitor and resistor to be exchanged another type of band-pass filter function namely

$$\frac{i_0}{i_{in}} = \frac{s^2}{(1 + 2s + s^2 + s^3)} \quad (3)$$

can be implemented. Resulting filter topology is illustrated in Fig. 1(b).



# Continuous-Time Filters

The core of the circuit consists of two unity voltage gain cells, two capacitors and two resistors and is shown in Fig. 2. The unity gain cells are replaced by second generation current conveyors to pick up the output current. The current transfer functions are given as,




Fig. 2. Core of proposed circuit consists of two unity voltage gain cells, two capacitors and two resistors.

# Continuous-Time Filters

$$i_{01} = sC_2(G_1i_{in1} - sC_1i_{in2})/\Delta(s) \quad (4)$$

$$i_{02} = -G_2(G_1i_{in1} - sC_1i_{in2})/\Delta(s) \quad (5)$$

where  $\Delta(s) = s^2C_1C_2 + sG_1C_1 + G_1G_2$ . Thus the core circuit can realize all the three basic filtering functions depending on the selection of the input and output ports.

# Continuous-Time Filters





Fig. 3. Experimental and theoretical frequency responses of proposed third-order Butterworth filters and sixth-order filter obtained by cascading topologies illustrated in Fig. 1(a) and Fig. 1(b) called Cell 1 and Cell 2, respectively.

# Continuous-Time Filters

## Wide Dynamic Range High Output Impedance Current-mode Multifunction Filters with Dual-output Current Conveyors



The  $\pm$  sign indicates whether the element is of p (DO-CCIIp) or n type (DO-CCII<sub>N</sub>). This active element has been used in other applications [18, 19]; bipolar [20] and CMOS realisations [21] are presented in literature. In case of non-ideal DO-CCII the definition equation converts to


$$\begin{bmatrix} v_x \\ i_y \\ i_{z1} \\ i_{z2} \end{bmatrix} = \begin{bmatrix} 0 & \beta & 0 & 0 \\ 0 & 0 & 0 & 0 \\ \alpha_1 & 0 & 0 & 0 \\ \pm\alpha_2 & 0 & 0 & 0 \end{bmatrix} \begin{bmatrix} i_x \\ v_y \\ v_{z1} \\ v_{z2} \end{bmatrix} \quad (1b)$$

where  $\alpha_1$ ,  $\alpha_2$  denote the current tracking and  $\beta$  denotes the voltage tracking coefficients respectively.


Fig. 1. The dual-output current conveyor symbol.

$$\begin{bmatrix} v_x \\ i_y \\ i_{z1} \\ i_{z2} \end{bmatrix} = \begin{bmatrix} 0 & 1 & 0 & 0 \\ 0 & 0 & 0 & 0 \\ 1 & 0 & 0 & 0 \\ \pm 1 & 0 & 0 & 0 \end{bmatrix} \begin{bmatrix} i_x \\ v_y \\ v_{z1} \\ v_{z2} \end{bmatrix}$$

# Continuous-Time Filters




(a)




(b)

# Continuous-Time Filters



(d)

(c)



(e)

# Continuous-Time Filters

$$H_{HP}(s) = \frac{H_1 s^2}{s^2 + \frac{\omega_0}{Q}s + \omega_0^2} \quad (2)$$

$$H_{LP}(s) = \frac{H_2 \omega_0^2}{s^2 + \frac{\omega_0}{Q}s + \omega_0^2} \quad (3)$$

$$H_{BP}(s) = \frac{H_3 \frac{\omega_0}{Q} s}{s^2 + \frac{\omega_0}{Q}s + \omega_0^2} \quad (4)$$

# Continuous-Time Filters

Topology	$\omega_o$	$Q$	$H_1$	$H_2$	$H_3$
Figure 2a	$\sqrt{\frac{G_1 G_2 G_3}{C_3 C_6 G_4}}$	$\frac{1}{C_1} \sqrt{\frac{G_1 G_4 C_3 C_6}{G_2 G_3}}$	1	$-\frac{G_4}{G_1}$	$\frac{G_4 C_6}{G_3 C_1}$
Figure 2b	$\sqrt{\frac{G_2 G_3 G_5}{C_1 C_4 G_6}}$	$\frac{1}{C_3} \sqrt{\frac{G_3 G_6 C_1 C_4}{G_2 G_3}}$	1	$\frac{G_6}{G_3}$	$\frac{G_6 C_1}{G_3 C_3}$
Figure 2c	$\sqrt{\frac{G_3 G_6}{C_2 C_4}}$	$\frac{1}{C_6} \sqrt{\frac{G_6 C_2 C_4}{G_3}}$	1	$\frac{G_1}{G_6}$	$\frac{C_2}{C_6}$
Figure 2d	$\sqrt{\frac{G_2 G_3}{C_1 C_4}}$	$\frac{1}{G_1} \sqrt{\frac{G_2 G_3 C_1}{C_4}}$	$-\frac{C_3}{C_1}$	1	$-\frac{G_4}{G_1}$
Figure 2e	$\sqrt{\frac{G_2 G_3}{C_1 C_5}}$	$\frac{1}{G_1} \sqrt{\frac{G_2 G_3 C_1}{C_5}}$	$-\frac{1}{2} \frac{C_4}{C_1}$	-1	$-\frac{G_4}{G_1}$



# Continuous-Time Filters

The passive sensitivities are calculated for the topology given in Figure 2a as

$$S_{G_1, G_2, G_3}^{\omega O} = 1/2, \quad S_{G_4, C_5, C_6}^{\omega O} = -1/2, \quad S_{C_1}^{\omega O} = 0,$$

$$S_{G_1, G_4, C_5, C_6}^{\omega} = 1/2, \quad S_{G_2, G_3}^{\omega} = -1/2, \quad S_{C_1}^{\omega} = -1,$$

for Figure 2b as,

$$S_{G_2, G_3, G_5}^{\omega O} = 1/2, \quad S_{C_1, C_4, G_6}^{\omega O} = -1/2, \quad S_{C_5}^{\omega O} = 0,$$

$$S_{C_1, C_4, G_5, G_6}^{\omega} = 1/2, \quad S_{G_2, G_3}^{\omega} = -1/2, \quad S_{C_5}^{\omega} = -1,$$

for Figure 2c as,

$$S_{G_5, G_6}^{\omega O} = 1/2, \quad S_{C_2, C_4}^{\omega O} = -1/2, \quad S_{G_1, C_6}^{\omega O} = 0,$$

$$S_{C_2, C_4, G_6}^{\omega} = 1/2, \quad S_{G_5}^{\omega} = -1/2, \quad S_{C_6}^{\omega} = -1, \quad S_{G_1}^{\omega} = 0,$$

for Figure 2d as,

$$S_{G_2, G_3}^{\omega O} = 1/2, \quad S_{C_1, C_4}^{\omega O} = -1/2, \quad S_{G_1, C_5}^{\omega O} = 0,$$

$$S_{C_1, G_2, G_3}^{\omega} = 1/2, \quad S_{C_4}^{\omega} = -1/2, \quad S_{G_1}^{\omega} = -1, \quad S_{C_5}^{\omega} = 0$$

and for Figure 2e as,


$$S_{G_2, G_3}^{\omega O} = 1/2, \quad S_{C_1, C_5}^{\omega O} = -1/2, \quad S_{G_1, C_4}^{\omega O} = 0,$$

$$S_{C_1, G_2, G_3}^{\omega} = 1/2, \quad S_{C_5}^{\omega} = -1/2, \quad S_{C_4}^{\omega} = 0, \quad S_{G_1}^{\omega} = -1$$

# Continuous-Time Filters

## Four Terminal Floating Nullor (FTFN) based filters

An FTFN is equivalent to an ideal nullor or is called operational floating amplifier.



$$I_1 = I_2 = 0 \quad I_{o1} = I_{o2} \quad V_x = V_y$$

Fig. 1. Nullor model and symbol of FTFN.

# Continuous-Time Filters

## Four Terminal Floating Nullor (FTFN) based filters


FTFN can be considered as a DOTA with infinite transconductance.  
Practically, DOTA with a very large  $g_m$ .

As a result:

$$I_1 = 0, I_2 = 0,$$

$$V^+ = V^-$$

$$I_{o1} = I_{o2}$$



# Continuous-Time Filters




Fig. 2. The proposed current-mode multifunction filter.

# Continuous-Time Filters

$$\frac{I_{LP}}{I_{in}} = \frac{G_1 G_2}{s^2 C_3 C_5 + s(C_3 + C_5)G_1 + G_1 G_2},$$

$$\omega_0 = \sqrt{\frac{G_1 G_2}{C_3 C_5}},$$

$$\frac{I_{HP}}{I_{in}} = \frac{-s^2 C_5 C_6}{s^2 C_3 C_5 + s(C_3 + C_5)G_1 + G_1 G_2}$$

$$\frac{\omega_0}{Q} = \frac{G_1(C_3 + C_5)}{C_3 C_5}$$

$$\frac{I_{BP}}{I_{in}} = \frac{-s C_5 G_4}{s^2 C_3 C_5 + s(C_3 + C_5)G_1 + G_1 G_2}$$

$$Q = \sqrt{\frac{G_2}{G_1} \frac{\sqrt{C_3 C_5}}{C_3 + C_5}}.$$

$$S_{R_1}^{\omega_0} = S_{R_2}^{\omega_0} = S_{C_3}^{\omega_0} = S_{C_5}^{\omega_0} = -S_{R_1}^Q = S_{R_2}^Q = -\frac{1}{2},$$

$$S_{C_3}^Q = S_{C_5}^Q = \frac{C_5 - C_3}{2(C_3 + C_5)}.$$

# Continuous-Time Filters

## Current Differencing Buffered Amplifier (CDBA)

The circuit symbol of the CDBA is shown in Figure 1a, where p and n are input, w and z are output terminals.

The equivalent circuit of the CDBA is given in Figure 1b.

The current differencing buffered amplifier is characterized by Eq. (1).

$$\begin{bmatrix} i_z \\ v_w \\ v_p \\ v_n \end{bmatrix} = \begin{bmatrix} 0 & 0 & 1 & -1 \\ 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 0 \\ 0 & 0 & 0 & 0 \end{bmatrix} \begin{bmatrix} v_z \\ i_w \\ i_p \\ i_n \end{bmatrix} \quad (1)$$




Fig. 1. a) Circuit symbol of CDBA. b) Equivalent circuit of CDBA.

# Continuous-Time Filters




Fig. 2. The proposed filter topology.

$$\frac{i_{o1}}{i_{in}} = \frac{\frac{G_2 s}{C_2}}{s^2 + \frac{G_1 + G_2 + G_3}{C_1} s + \frac{G_1 G_2}{C_1 C_2}} \quad (2)$$

$$\frac{i_{o2}}{i_{in}} = \frac{\frac{G_2 G_3}{C_1 C_2}}{s^2 + \frac{G_1 + G_2 + G_3}{C_1} s + \frac{G_1 G_2}{C_1 C_2}} \quad (3)$$

$$\frac{i_{o3}}{i_{in}} = \frac{s^2 + \frac{G_1 + G_2 + G_3}{C_1} s}{s^2 + \frac{G_1 + G_2 + G_3}{C_1} s + \frac{G_1 G_2}{C_1 C_2}} \quad (4)$$

# Continuous-Time Filters

$$\omega_p = \sqrt{\frac{G_1 G_2}{C_1 C_2}} \quad (5)$$

$$Q_p = \frac{1}{G_1 + G_2 + G_3} \sqrt{\frac{G_1 G_2 C_1}{C_2}} \quad (6)$$

$$S_{G_1}^{\omega_p} = S_{G_2}^{\omega_p} = 1/2 \quad S_{G_3}^{\omega_p} = 0$$

$$S_{C_1}^{\omega_p} = S_{C_2}^{\omega_p} = -1/2$$

$$S_{G_1}^{Q_p} = \frac{G_2 - G_1 + G_3}{2(G_1 + G_2 + G_3)}$$

$$S_{G_2}^{Q_p} = \frac{G_1 - G_2 + G_3}{2(G_1 + G_2 + G_3)}$$

$$S_{G_3}^{Q_p} = -\frac{G_3}{G_1 + G_2 + G_3}$$


$$S_{C_1}^{Q_p} = 1/2$$

$$S_{C_2}^{Q_p} = -1/2$$



# Continuous-Time Filters

## Differential Voltage Current Conveyors: DVCC



The DVCC has the advantages of both of the second generation current conveyor (CCII) (such as large signal bandwidth, great linearity, wide dynamic range) and the differential difference amplifier (DDA) (such as high input impedance and arithmetic operation capability)

Fig. 3. Electrical symbol of the DVCC.

$$\begin{bmatrix} V_X \\ I_{Y1} \\ I_{Y2} \\ I_{Z1} \\ I_{Z2} \end{bmatrix} = \begin{bmatrix} 0 & 1 & -1 & 0 & 0 \\ 0 & 0 & 0 & 0 & 0 \\ 0 & 0 & 0 & 0 & 0 \\ 1 & 0 & 0 & 0 & 0 \\ -1 & 0 & 0 & 0 & 0 \end{bmatrix} \begin{bmatrix} I_X \\ V_{Y1} \\ V_{Y2} \\ V_{Z1} \\ V_{Z2} \end{bmatrix}.$$

# Continuous-Time Filters






Fig. 5. The basic signal processing block of implementing CM KHN-biquad.



(a)



(b)

# Continuous-Time Filters

$$\frac{I_{HP}}{I_{in}} = \frac{(R_1/R_2)s^2}{s^2 + (1/C_1R_2)s + (R_1/R_2R_3R_4C_1C_2)}, \quad (4a)$$

$$\frac{I_{BP}}{I_{in}} = -\frac{(R_1/R_2R_3C_1)s}{s^2 + (1/C_1R_2)s + (R_1/R_2R_3R_4C_1C_2)}, \quad (4b)$$

$$\frac{I_{LP}}{I_{in}} = \frac{(R_1/R_2R_3R_4C_1C_2)}{s^2 + (1/C_1R_2)s + (R_1/R_2R_3R_4C_1C_2)}. \quad (4c)$$

The natural angular frequency  $\omega_0$  and the quality factor  $Q$  of the filter can be expressed as

$$\omega_0 = \sqrt{\frac{R_1}{R_2R_3R_4C_1C_2}}, \quad Q = \sqrt{\frac{R_1R_2C_1}{R_3R_4C_2}}. \quad (5)$$

# Continuous-Time Filters

## Current Differencing Transconductance Amplifier : CDTA




Fig. 1. Symbol of the CDTA element.

$$V_p = V_n = 0, \quad I_z = I_p - I_n,$$
$$I_{x+} = gV_z, \quad I_{x-} = -gV_z.$$

Current differencing transconductance amplifier (CDTA) is a recently reported current-mode active building block.

# Continuous-Time Filters




Fig. 8. Seventh-order passive elliptic low-pass filter.




Fig. 9. Seventh-order passive elliptic low-pass filter employing CDTAs.

# Continuous-Time Filters




Fig. 11. Ideal and simulated filter responses.

## References

- U. Çam, O. Çiçekoğlu, H. Kuntman, Current-mode single-input three outputs (SFTO) universal filter employing FTFNs and reduced number of passive components, *Frequenz*, Vol.54, No.3-4, pp.94-96, 2000.
- U. Çam, O.Çiçekoğlu, M. Gülsoy, H. Kuntman, 'New voltage and current mode first-order all-pass filters using single FTFN', *FREQUENZ*, No.7-8, pp 177-179, 2000.
- Çam U., Tokar A., Çiçekoğlu O., Kuntman H, Current-mode high output impedance multifunction filters employing minimum number of FTFN, *Analog Integrated Circuits and Signal Processing*, vol. 28, pp. 299-307, 2001.
- O. Çiçekoğlu, N. Tarım, H. Kuntman, , Wide Dynamic Range High output impedance current-mode multifunction filters with dual-output current conveyors providing wide dynamic range, *AEÜ: International Journal of Electronics and Communications*, 56, No.1, pp. 55-60, 2002.
- H. Kuntman, O. Çiçekoğlu, S. Özcan, "Realization of current-mode third order butterworth filters employing equal valued passive elements and unity gain buffers" *Analog Integrated Circuit and Signal Processing*, Vol.30, pp.253-256, 2002.
- S. Minaei, O. Cicekoglu, H. Kuntman, G. Dunder and Ö. Cerid, "New Realizations of Current-Mode and Voltage-Mode Multifunction Filters without External Passive Elements", *AEÜ – International Journal of Electronics and Communications*, Vol. 57, No. 1, pp. 63-69, 2003.
- R. Topaloğlu, H. Kuntman, O. Çiçekoğlu, "Current-Input Current-Output Notch and Bandpass Analog Filter Structures as Alternatives to Active-R Circuits", *FREQUENZ*, Vol.57, No. 5-6, pp.124-128, 2003.
- M. Aksoy, S. Ozcan, O. Çiçekoglu and H. Kuntman, " High Output Impedance Current Mode Third Order Butterworth Filter Topologies Employing Unity Gain Voltage Buffers and Equal-Valued Passive Components", *International Journal of Electronics*, vol. 90, No.9, pp. 589-598, 2003.
- E. S. Erdogan, R. O. Topaloglu, O. Çiçekoglu and H. Kuntman, "New Current-mode Special Function Continuous Time Active Filters Employing Only OTAS and Opamps", *International Journal of Electronics*, Volume 91, Number 6, 345 – 359, 2004.
- M. A. Ibrahim, S. Minaei and H. Kuntman, "A 22 MHz current-mode KHN-biquad using differential voltage current conveyor and grounded passive elements", *AEU: International Journal of Electronics and Communications*, Volume 59, 311–318, 2005.

- S. Minaei, O. K. Sayin and H. Kuntman, "A New CMOS Electronically Tunable Current Conveyor and Its Application to Current-Mode Filters, IEEE Transactions on Circuits and Systems I, TCAS-I, Volume 53, No.7, 1448-1457, 2006.
- E. S. Erdogan, R. O. Topaloglu, O. Cicekoglu, H. Kuntman and A. Morgül, "Novel multiple function analog filter structures and a dual-mode multifunction filter, International Journal of Electronics, Volume 93, No.9, 637 - 650, 2006.
- M. Altun and H. Kuntman, "Design of a Fully Differential Current Mode Operational Amplifier with Improved Input-Output Impedances and Its Filter Applications", AEU: International Journal of Electronics and Communications, Vol.62, No. 3, 239-244, 2008.
- F. Kacar, B. Metin, H. Kuntman, "A New Dual-X CMOS Second Generation Current Conveyor (DXCCII) with a FDNR Circuit Application", accepted for publication in AEU: International Journal of Electronics and Communications (A08-326).
- S. Özcan, H. Kuntman and O. Çiçekoğlu, "Current mode filters for multipurpose applications employing a single CDBA and only grounded capacitors", Proc. of the 7th Int. Conference on optimization of electrical and electronic equipment (OPTIM'2000), Brasov, Romania, May 11-12, 2000, 783-786.
- S. Minaei, M. A. Ibrahim and H. Kuntman, "A New Current-Mode KHN-Biquad Using Differential Voltage Current Conveyor Suitable for IF Stages, Proc. of ISSPA 2003: Seventh International Symposium on Signal Processing and its Applications, CD-ROM, 1-4 July 2003, Paris, FRANCE
- A. Uygur and H. Kuntman, "Novel Current-Mode Biquad Using A Current Differencing Transconductance Amplifier, Proceedings of Applied Electronics 2005, pp. 349-352, Pilsen, Czech Republic, 7-8 September 2005.
- A. Ü. Keskin, E. Hancıoğlu and H. Kuntman, "Current mode KHN-Equivalent biquad using dual-output current conveyors, Proceedings of ELECO 2005: The 4th International Conference on Electrical and Electronics Engineering, (Electronics), pp. 37-40, 7-11 December 2005, Bursa, Turkey.
- S. Minaei, O. K. Sayin, H. Kuntman, "Nth-Order Current Transfer Function Synthesis Using a High-Performance Electronically Tunable Current Conveyor" Proceedings of MELECON'06: The 13th IEEE Mediterranean Electrotechnical Conference, pp.15-18, 16-19 May 2006, Benalmádena, Málaga, Spain.
- C. Toumazou, F.J. Lidgley, D.G. Haigh (ed.), "Analog IC design: the current-mode approach", Peter Peregrinus Ltd., 1998.